

# 'White Cover' application in 6 easy steps



1. Prepare the pallet and lay the cover ready for loading.



2. Put cargo on top and fold the bottom part up onto the load.



3. Fix using Velcro attachments,



4. Place the hood on the top and fasten the loops.



5. The pallet with top and bottom pieces fastened.



6. Apply the pallet net and restrain the load as normal.